


Programming interface cable (P/N: 02000051)


To use with: P145 U245 (P/N: 12xxxxxx 13xxxxxx 23xxxxxx 24xxxxxx 26xxxxxx)

rev00




Programming interface cable (P/N: 02000052)  
 To use with: **U245 (P/N: 25xxxxxx)**

rev00




Programming interface cable (P/N: 02000053)  
To use with: **P177 (P/N: 11xxxxxx)**

rev00



Programming interface cable (P/N: 02000054)  
To use with: **U277 (P/N: 32xxxxxx)**


rev00



Programming interface cable (P/N: 02000057)


To use with: U122 U322 U333 (P/N: 20xxxxxx 27xxxxxx 38xxxxxx 39xxxxxx)

rev00




Programming interface cable (P/N: 02000058)  
To use with: **U193 (P/N: 21xxxxxx 22xxxxxx)**

rev00



Programming interface cable (P/N: 02000059)  
To use with: **U193 (P/N: 29xxxxxx)**

rev00




O351  
Connector

U355  
Connector

Programming interface cable (P/N: 02000060)  
To use with: **U355 (P/N: 28xxxxxx)**


rev00






Programming interface cable (P/N: 02000061)  
To use with: **U355 (P/N: 30xxxxxx)**

rev00




Programming interface cable (P/N: 02000062)  
To use with: **U445 (P/N: 35xxxxxx)**

rev00



Programming interface cable (P/N: 02000063)  
To use with: **U445 (P/N: 33xxxxxx 34xxxxxx)**

rev00




O351  
Connector

U245 5V  
Connector

Programming interface cable (P/N: 02000064)  
To use with: **U245 5V (P/N: 37xxxxxx)**

rev00



O351  
Connector

X022  
Connector

Programming interface cable (02000065)  
To use with: **X022 (P/N: 0055xx00)**

rev00